

Recommended Vibrance Luster Print Settings

The Breathing Color Vibrance Luster photo paper was designed specifically to be used with the Epson™ Premium Luster Photo Paper driver settings to obtain maximum results. Please use the following settings :

EPSON Printers

Stylus Pro 4800 | 4880 | 7800 | 7880 | 7900 | 9800 | 9880 | 9900 | 11880

- Vibrance Luster Photo Paper



Use these settings in the Epson Driver:

- Print Preview Window (photoshop) - Printer Manages Color
- Media type: Premium Luster Photo Paper
- Print Quality: SuperFine 1440x720dpi
- Paper Configuration: Platen Gap (Standard)
- Mode: (Custom) Color Controls - Advanced (Adobe RGB)
- Paper Settings - Roll Paper (Banner)
- Roll Paper Option: Auto Cut
- Paper Suction: Standard